

## DV Masons Form Instructions

The Ironhaus DV mason form benefits the contractor, mason and home owner in several ways. The form provides a predictable template for the mason while guaranteeing a final straight edge for a door to cover later. Since custom doors can take 4-6 weeks to build, and a mason form takes generally less than a week, work flows can be continued without delays. Doors can be installed easily later, after the mess and risk of damage from construction is over.



1. Square template to top & bottom on the DV unit.

2. Screw the template to framing using the appropriate fastener.



4. Bend the welded tabs on the door frame inward.

5. Measure the distance that you have for the welded tabs to go inward on the DV unit / DV template, (in this case we have 2”).

6. Trim the welded tabs, if needed to the measured length..

3. Template is attached to the framing and is ready to be rocked in, then receive the door.



6. Pre-drill a pilot hole through welded tab and through the DV template. Install screw through welded tabs and into the DV template securing the door.

