

Lifestyle Series, Heritage Series, & Traditional Series Install Instructions



Direct vent gas fireplace before mounting a Lifestyle Series or Heritage Series door.



Louvered zero clearance woodburning fireplace before mounting a Traditional Series door.



1. Bend the welded tabs on the door frame inward.



2. Measure the distance that you have for the welded tabs to go inward on the unit where the frame will be installed (in this case we have 2").



3. Trim the welded tabs, if needed to the measured length..



4. Predrill a pilot hole through welded tab and through the unit. Install screw through welded tabs and into the unit securing the frame to the unit.